REMOTE INDICATION, SENSING RESISTORS

REMOTE INDICATION & METERS

Product	Features	Accessory For
RK-302 Remote Indication and Reset Kit 	Panel-mounted remote indication and reset, standard 22 mm mounting with NEMA 4 and NEMA 13 rating.	**SE-325**
RK-332 Remote Indication and Reset Kit 	Panel-mounted remote indication and reset, standard 22 mm mounting with NEMA 4 and NEMA 13 rating.	**SE-330 SE-330AU SE-330HV**
PGB-6130 Remote Indication and Reset Assembly 	Remote indication of overcurrent, phase unbalance, phase loss, phase sequence, and overtemperature. Remote reset included.	**PGR-6130**
PGB-6800 Remote Indication and Reset Assembly 	Remote indication of overcurrent, undercurrent, phase unbalance, phase loss, and phase sequence. Remote reset included.	**PGR-6800**
PGA-0500 Analog % Current Meter 	Panel-mounted analog meter displays ground-fault current as a percentage of the set point.	**SE-601 SE-701 PGR-4300 SE-703 PGR-6100 SE-704**
PGA-0510 Analog Ohm Meter 	Panel-mounted analog ohmmeter displays insulation resistance from 0 Ω to infinity.	**PGR-3200 PGR-6100**
E2323 & E2324 Megaohmmeter & Kiloohmmeter 	Flush-mounted units designed for connection with the T3200 for instrument readings.	**T3200**
M8100 Synchroscope 	Flush-mounted units provide illuminaated indication of the phase and frequency difference between voltages on two separate AC systems.	**T5000 T4500 C6200 FlexGen S6000 Sigma**

SENSING RESISTORS

Product	Features	Accessory For
ER-600VC (PGE-600V) Sensing Resistor 	Used on systems up to 1 kV. (Continuous duty)	**SE-330 SE-325 SE-330AU**
SE-MRE-600 Enclosure 	Used in outdoor enclosures. (ER-600VC ordered separately)	**ER-600VC**
ER-5KV (PGE-05KV) Sensing Resistor 	Used on systems up to 5 kV. (Continuous duty)	**SE-330 SE-325 SE-330AU**
ER-5WP (PGE-05WV) Sensing Resistor 	Used on systems up to 5 kV, includes weather-protected terminals for use in outdoor enclosures. (Continuous duty)	**SE-330 SE-325 SE-330AU**
ER-15KV (PGE-15KV) Sensing Resistor 	Used on systems up to 15 kV. (Non-continuous duty)	**SE-330 SE-325 SE-330HV SE-330AU**
ER-25KV (PGE-25KV) Sensing Resistor 	Used on systems up to 25 kV. (Non-continuous duty)	**SE-330 SE-325 SE-330HV SE-330AU**
ER-35KV (PGE-35KV) Sensing Resistor 	Used on systems up to 35 kV. (Non-continuous duty)	**SE-330 SE-330HV SE-330AU**
ER-72KV (PGE-72KV) Sensing Resistor 	Used on systems up to 72 kV. (Non-continuous duty)	**SE-330HV**